

GT1 Soft Gelato Machine

CLEANING INSTRUCTIONS



1. Unlock the top lid and remove.



2. Remove the clear bowl lid.




3. Press both sides of the dispensing handle and remove by pulling upwards.




4. Unscrew both bowl screws counter-clockwise.




5. Remove bowl by pulling forward.




6. Unscrew blade by rotating the front knob clockwise.



7. Remove blade by pulling forward.



8. Remove front white rubber gasket.




9. Remove rear red rubber gasket.




10. Clean the interior and exterior of the machine for best maintenance and performance.

*After thorough cleaning of the machine, 3 parts need lubrication to avoid leaking, technical problems and to maintain an overall quiet operation of the machine.



A) Lubricate along the inside of the front white rubber gasket.



B) Lubricate along the inside and outside of the rear red rubber gasket.



C) Lubricate the around the 2 clean rings on the dispensing handle

*Now put it all back together in reverse of the instructions and enjoy!